
### LoPro®BELT INSTALLATION


#### INSTRUCTIONS:

- 1. REMOVE ADJUSTMENT SCREW FROM IDLER END.
  2. REMOVE COVERS FROM DRIVE END AND IDLER END.
  3. SLIDE YOKE ASSEMBLY OUT OF IDLER END. THREAD BELT THROUGH IDLER END AND THEN THROUGH BOTTOM OF YOKE ASSEMBLY, THEN OVER THE PULLEY.

  4. PLACE IDLER END COVER AGAINST YOKE ASSEMBLY. THREAD ADJUSTMENT SCREW
- LOOSELY INTO YOKE.
- 5. SLIDE YOKE ASSEMBLY AND BELT INTO IDLER END HOUSING, UNTIL IDLER END COVER IS AGAINST THE IDLER END HOUSING, THREADING THE BELT THROUGH IDLER END HOUSING.

- 6. REPLACE IDLER END COVER SCREW. TIGHTEN COVER SCREWS.
  7. THREAD OTHER END OF BELT THROUGH BOTTOM OF THE DRIVE END ASSEMBLY.
  8. ROUTE BELT OVER PULLEY AND BACK THROUGH DRIVE END ASSEMBLY.
  9. REPLACE DRIVE END COVER. REPLACE DRIVE END COVER SCREW. TIGHTEN COVER SCREWS.










## LoPro® BELT INSTALLATION


BELT INSTALLED THROUGH DRIVE ENDS. SEE MANUAL LPWWPBAMAN OR LPBWPBAMAN FOR ATTACHING BELT TO WHEEL PLATE.






### LOPRO BASIC WHEEL PLATE BELT ATTACHMENT


- 1. PLACE THE WHEEL PLATE ON THE TRACK PLATE ASSEMBLY, TAKING CARE NOT TO DAMAGE THE LUBRICATING FELTS.
- 2. SLIDE THE WHEEL PLATE TO DNE END OF THE TRACK, ENSURING THAT THE BELT PASSES UNDER IT COMPLETELY.
- 3. PLACE THE BELT COUPLER IN THE TRACK PLATE CHANNEL, BETWEEN THE ENDS OF THE BELT.




4. PULL THE ENDS OF THE BELT TOGETHER TO ELIMINATE AS MUCH SLACK AS POSSIBLE, AND PLACE THE ENDS OF THE BELT ON THE COUPLER, SUCH THAT THE BELT AND COUPLER TEETH ARE ENGAGED.



5. MOVE THE WHEEL PLATE OVER THE BELT COUPLER, TAKING CARE NOT TO DISPLACE THE ENDS OF THE BELT FROM THE COUPLER.



6. ALIGN THE MOUNTING HOLES OF THE WHEEL PLATE AND THE BELT COUPLER, AND SECURE THE COUPLER TO THE WHEEL PLATE WITH THE APPROPRIATE SCREWS.




This document is proprietary to the Bishop-Wisecarver Corporation and is for the use of its employees, representatives and customers.


LPBWPBAMAN

REV: B PAGE:

1 of 2

# Lopro Basic wheel plate Belt attachment








This document is proprietary to the Bishop-Wisecarver Corporation and is for the use of its employees, representatives and customers.

LPBWPBAMAN

REV:B PAGE: 2 of 2

# LoPro Basic wheel plate maintenance


#### EXPLODED VIEW OF LUBRICATOR / WHEEL COVER ASSEMBLIES






#### Lopro Basic wheel plate maintenance

#### ECCENTRIC BUSHING ADJUSTMENT



#### Lopro Basic Wheel Plate Maintenance

#### EXPLODED VIEW OF WHEEL PLATE SHOWING WHEEL REPLACEMENT





REV: B PAGE:

LPBWPMAN

3 of 3


### Lopro dual vee wheel fit-up

TO OBTAIN THE BEST PERFORMANCE FROM A Bishop-Wisecarver LoPro LINEAR MOTION SYSTEM, CARE SHOULD BE TAKEN TO ENSURE THE WHEEL PLATE IS CORRECTLY ADJUSTED.

ADJUSTMENT OF PRELOAD FOR STUDDED GUIDE WHEELS:

THE GUIDE WHEELS HAVE INTEGRATED STUDS AND WRENCH FLATS ON THEIR INNER RACES. THE CONCENTRIC GUIDE WHEELS ATTACH DIRECTLY TO TAPPED HOLES ON THE WHEEL PLATE. THE ECCENTRIC GUIDE WHEEL STUDS PASS THROUGH CLEARANCE HOLES ON THE WHEEL PLATE AND ARE HELD TO THE WHEEL PLATE BY FLANGED HEX NUTS ON THE WHEEL PLATE'S TOP SIDE.

- 1. CHECK CONCENTRIC GUIDE WHEEL MOUNTING BOLTS FOR TIGHTNESS.
- 2. USE A SOCKET WRENCH TO LOOSEN THE ECCENTRIC GUIDE WHEEL'S FLANGED HEX NUT JUST ENOUGH TO ALLOW ROTATION OF THE ECCENTRIC WHEEL'S WRENCH FLAT. MAKE THE FOLLOWING ADJUSTMENTS IN SMALL INCREMENTS.
- 3. PLACE THE WHEEL STUD WRENCH ON THE ECCENTRIC WHEEL'S WRENCH FLAT AND ROTATE THE HANDLE AWAY FROM THE CENTER OF THE WHEEL PLATE TO A POINT WHERE THE GUIDE WHEELS CONTACT THE TRACK.
- 4. HOLD THE GUIDE WHEEL FIRMLY BETWEEN YOUR FINGERS AND MOVE THE WHEEL PLATE ALONG THE TRACK. AT THE SAME TIME, ROTATE THE BUSHING TO A POINT WHERE THE GUIDE WHEEL DOES NOT SKID ON THE TRACK. TIGHTEN THE FLANGED HEX NUT SNUGLY SO THAT THIS TEMPORARY ADJUSTMENT WILL HOLD.
- 5. REPEAT THIS PROCEDURE ON THE SECOND ECCENTRIC GUIDE WHEEL.
- 6. A PROPER ADJUSTMENT IS ACHIEVED BY REPEATING STEPS 4 AND 5 UNTIL A UNIFORM RESISTANCE TO MOTION IS ATTAINED BY "FEEL" ALONG THE ENTIRE TRACK.
- 7. FULLY TIGHTEN THE ECCENTRIC WHEEL BOLTS TO FIX BOTH ADJUSTMENTS. NOTE THAT BOTH ECCENTRIC WHEELS NEED TO BE ADJUSTED PRIOR TO PERFORMING THIS FINAL TIGHTENING SO AS TO AVOID BINDING OF THE CARRIAGE.
- 8. APPLY WICKING THREAD LOCKER TO WHEEL BOLT THREADS FROM TOP OF WHEEL PLATE. USE LOCTITE 290 OR EQUIVALENT.



This document is proprietary to the Bishop-Wisecarver Corporation and is for the use of its employees, representatives and customers.

LPWFSMAN

REV: A PAGE: 1 of 1

### LOPRO BELT OR CHAIN TENSIONING

TO ADJUST BELT OR CHAIN TENSION:

- 1. MOVE WHEEL PLATE TO DRIVEN END OF SYSTEM.
- 2. TIGHTEN OR LOOSEN ADJUSTMENT SCREW LOCATED ON IDLER END COVER.
- 3. THIS WILL SLIDE YOKE ASSEMBLY IN THE IDLER END HOUSING.
- 4. ADJUST UNTIL DESIRED TENSION IS ACHIEVED.

#### GENERAL

LoPro SYSTEM LENGTH, LOAD, SPEED, AND ACCELERATION PROFILES ALL AFFECT THE DRIVE TENSION REQUIRED FOR CONSISTENT, TROUBLE-FREE OPERATION. IN GENERAL, OVER-TENSIONING THE SYSTEM SHOULD BE AVOIDED TO PREVENT PREMATURE WEAR OF DRIVE SYSTEM COMPONENTS.


#### BELT DRIVEN Lopro SYSTEMS

THE IDEAL TENSION IN LINEAR DRIVE BELT SYSTEMS IS ACHIEVED WHEN THE TENSILE FORCE IS EQUAL TO THE TRANSMITTED FORCE. THE TRANSMITTED FORCE IS THE FORCE IN THE BELT WHEN IT ACCELERATES OR DECELARATES THE LOAD. THE FORCE IS EQUAL TO THE LOAD MASS X ACCELERATION + FRICTION


THE BELT TENSION CAN BE DIFFICULT TO ESTIMATE WHILE ADJUSTING YOUR LOPFO SYSTEM. THE BELT SHOULD FEEL FIRM WHEN PRESSED UPON WITH A FINGER, BUT NEVER BE 'GUITAR STRING' TIGHT WHEN TAPPED WITH A FINGER. THE BELT TENSION IS CORRECTLY SET WHEN THE SLACK SIDE OF THE BELT REMAINS TAUT UNDER MAXIMUM OPERATING LOAD. BELT FLAP OR SAGGING IS INDICATIVE OF INSUFFICIENT TENSION.


#### CHAIN DRIVEN Lopro SYSTEMS

HORIZONTALLY MOUNTED CHAIN DRIVEN LOPPO SYSTEMS WILL HAVE SIGNIFICANT VARIATIONS IN CHAIN TENSIONING REQUIREMENTS, NAMELY DUE TO THE VARYING LENGTHS OF THE SYSTEM. FOR SHORTER TRAVEL LENGTHS, THE CHAIN CAN BE TENSIONED TO PREVENT CONTACT WITH THE TRACK PLATE. FOR LONGER SYSTEMS, THE TENSION TO SUPPORT THE CHAIN WEIGHT WOULD BE EXCESSIVE, A WEAR STRIP WOULD BE REQUIRED. CHAIN DRIVEN LOPPO IN SIZES 3 AND 4 ARE PROVIDED WITH A UHMW POLYETHYLENE STRIP, WHICH IS FIXED TO THE TRACK PLATE FOR A REDUCED FRICTION CHAIN SUPPORT.



### LoPro TRACK PLATE MAINTENANCE





TO DETERMINE HALF HOLE AND END SPACES:


TPL = TRACK PLATE LENGTH L = TRACK PLATE MOUNTING HOLE SPACING

 $[(TPL\times2)/L]-.36 = INTEGER NUMBER AND DECIMAL VALUE$ INTEGER NUMBER/2 = NUMBER OF SPACES
A VALUE WITH .5 REPRESENTS A HALF HOLE
[(DECIMAL VALUE + .36) X L/2]/2 = END SPACES



LPTPAMAN

# LoPro°system drive end mounting



LoPro DRIVE/IDLER END	MDUNTING HARDWARE SIZE	END TO MOUNTING HOLE DIM A	MINIMUM SCREW LENGTH DIM B
1	M3	6.0 mm [.236 In] Max.	22.0 mm [.866 In]
52	M5	10.0 mm [.394 In] Max.	30.0 mm [1.181 ln]
2L	M5	10.0 mm [.394 ln] Max.	35.0 mm [1.378 ln]
3	M6	13.0 mm [.511 ln] Max.	45.0 mm [1.772 ln]
4	M8	13.5 mm [.531 ln] Max.	55.0 mm [2.165 ln]

This document is proprietary to the Bishop-Visecarver Corporation and is for the use of its employees, representatives and customers.

LPBCDEMMAN

REVIA PAGE: 1 of 1